

Assembly Instructions



Step 1 Remove the 2-10mm bolts holding the throttle cable bracket directly behind the throttle body. The bracket will spring away from the holes slightly, this is normal.



Step 2 Remove the 2-10mm bolts holding the top of the alternator to the alternator support bracket. This will not damage the alternator in any way.



Step 3 Place the cover mounting bracket so that the 2 holes on the large leg align with the holes in the alternator and the 2 holes on the short leg align with the holes in the throttle cable bracket. Replace the 10mm bolts that you removed in the previous steps through the cover bracket and into their locations. You will find that you will have to re-align the throttle cable bracket with its mounting holes. This is normal.



Step 4 Tighten the rear bolts holding the throttle cable bracket using a 10mm socket. Try to center the bracket from front to rear as best as possible before tightening.



Step 5 Tighten the front bolts holding the alternator bracket.



Step 6 Place the cover aligning the hole in the center of the cover with the hole in the center of the bracket. Thread in the 1/4-20 screw provided and tighten. Some minor positioning of the cover may be required to get it to sit correctly.

If you have any questions or problems, please e-mail us at sales@midwestautogear.com.