



Midwest Auto Gear

262-367-8254

www.midwestautogear.com

V8 Engine Plenum Cover Installation Instructions

Compatible with 2005-2007 Ford Mustang GT's

1

1. Remove bolt caps on fuel rail studs. (Inset 1)



2. Using 8 mm wrench, remove 4 studs from left and right fuel rail brackets. (Inset 2)

2



3. Lower back of Engine Plenum Cover into position to clear the firewall. (Inset 3)

3



4. Align mounting holes in Engine Plenum Cover with those in plenum. (Inset 4)

4



5. Replace 4 studs in left and right fuel rails and tighten with 8 mm wrench. **IMPORTANT:** Do not over tighten! (Inset 5)

5



6. Call your friends over and show off your cool engine compartment.



6