

## Installation Instructions Body Colored Radiator Cover



**Step 1:** Pull out the 6 push pin fasteners in the locations shown above. The pins are removed by prying up the head in the center and then pulling them out.

**Step 2:** Remove the old radiator cover by pulling the front lip out and then lifting off.

**Step 3:** Place the new radiator cover in place making sure the front edge is under the flange. Line up the holes for the push pins.

**Step 4:** Replace the push pin fasteners by placing them in the mounting holes and then pushing the heads down until flush.

Questions? We can be reached by e-mail [sales@midwestautogear.com](mailto:sales@midwestautogear.com) or by phone: **262-367-8254**

